



NOTES:

1. CORE HOLE TO BE SIZED FOR LINK SEAL. AFTER HOLE IS CORED IN WALL, CLEAN HOLE AND PROVIDE COATING OF SIKADUR 62 EPOXY TO THE INSIDE FACE OF THE CORE HOLE TO COVER EXPOSED ENDS OF REBAR. LET EPOXY CURE FOR THE FILL TIME RECOMMENDED BY MFR PRIOR TO INSTALLING PIPE AND LINK SEAL.

DOUBLE LINK SEAL - EXISTING WALL
NOT TO SCALE